




Operating manual
Electropneumatic Positioner ARCAPRO® - Version
without/with HART-Communication
Series 827A.E/X

Original instructions

© ARCA Regler GmbH. All rights reserved.

Cover picture background: Freepik.com

Table of Contents

1	General data	5
1.1	Validity of the manual	5
1.2	Contact details	5
1.3	Other applicable documents	5
1.4	Place of storage of the manual	5
1.5	ARCA ONSITE	5
2	Safety	7
2.1	Introduction	7
2.2	General safety information	7
2.3	Explanation of symbols and notices	7
2.4	Warning symbols on the device	8
2.5	Intended use	8
2.6	Improper modifications to the device	9
2.7	Qualified Personnel	9
2.8	Liability disclaimer	9
2.9	Laws and regulations	9
2.10	Conformity to directives	10
2.10.1	Conformity to European directives	10
2.11	Use in potentially explosive areas	10
3	Transport, storage and packaging	12
3.1	Transport	12
3.2	Storage	12
3.3	Packaging	12
4	Type plate	13
5	Type key	14
6	Description	16
6.1	Function	16
6.2	Construction	16
6.3	Device Components	18
6.3.1	Motherboard	18
6.3.2	Electrical Connections	18
6.3.3	Pneumatic Connections	19
6.3.4	Purging Air Switch	20
6.3.5	Restrictors	21
7	Assembly	22
7.1	Safety instructions for assembly	22
7.2	Mounting a linear actuator	23
7.2.1	Mounting with mounting kit for "Integrated Fitting Linear Actuator"	23
7.2.2	Mounting with mounting kit "Linear actuator IEC 60534"	25

7.3	Mounting with mounting kit "Rotary actuator VDI/VDE 3845"	28
7.4	Use of positioners in humid environment	31
8	Electrical connection	33
8.1	Electrical connection of basic device	35
8.2	Electrical connection options	36
8.3	Optional version M12 plug	40
9	Pneumatic connection	42
10	Commissioning.....	43
10.1	Preparation for commissioning of linear actuators	45
10.1.1	Automatic initialisation of linear actuators	46
10.1.2	Manual initialisation of linear actuators.....	47
10.2	Preparation for commissioning of rotary actuators	49
10.2.1	Automatic initialisation of rotary actuators	49
10.2.2	Manual initialisation of rotary actuators	50
10.3	Copying Initialisation Data (Positioner Exchange).....	51
11	Parameter overview.....	53
11.1	Parameters 1 to 5	53
11.2	Parameters 6 to 52	54
11.3	Parameters A to P	57
12	Service and maintenance	59
13	Technical Data	61
14	Fault removal	69
15	Disposal and recycling	72

1 General data

This operating manual contains instructions that enable the product to be safely and properly installed, put into operation and maintained.

The target group for this operating manual is exclusively specially trained and authorised technical personnel.

Please contact the manufacturer if you encounter problems that cannot be solved with the aid of this operating manual.

The product is subject to technical changes at any time.

1.1 Validity of the manual

This operating manual applies to the product in the version described in the device pass.

1.2 Contact details

Further information about the product can be obtained from:

Manufacturer's address

ARCA Regler GmbH
Kempener Str. 18
D-47918 Tönisvorst
Tel.: +49 (0) 2156-7709-0
Fax: +49 (0) 2156-7709-55
E-mail: sale@arca-valve.com
www.arca-valve.com

1.3 Other applicable documents

The product can be delivered as part of an actuator and equipped with additional components that are described in their own operating manuals. The instructions as well as the warning and safety information contained therein must also be observed.

Furthermore, the following documents apply in addition to this operating manual.

- Device pass
- Installation drawing

1.4 Place of storage of the manual

The operating manual and all other applicable documents are part of the product. They must be kept in the immediate vicinity of the product and must be accessible to the personnel at all times.

1.5 ARCA ONSITE

If the product was supplied as part of a complete control valve, the operating documentation can be downloaded from our ARCA ONSITE portal with the help of the control valve's serial number.

Two options are available here:

1. Scan the **QR code**¹, which can be found on the control valve. Further entries are not required.

2. Visit the website **<https://onsite.arca-valve.com/search>** and enter the ARCA order no. and ARCA serial no. of the control valve. The order no. and serial no. of the control valve can be found on the device pass and on our order confirmation.

Entry example

2512345	1234567
Search	Clear

[← back / zurück](#)*Illustration 1: ARCA ONSITE*

¹ **QR Code** is a registered trademark of DENSO WAVE INCORPORATED

2 Safety

2.1 Introduction

This manual contains all the information you need for the connection and commissioning of the device.

It is addressed to people who mechanically mount, electrically connect, parameterise and commission the device, as well as service and maintenance technicians.

This manual applies to devices from firmware version 5.00.00 in both non-intrinsically and intrinsically safe versions.

We expressly state that the contents of this operating manual do not form part of or modify a former or existing agreement, assurance or legal relationship. All obligations are specified in the particular purchase contract which also contains all the applicable warranty regulations. These contractual warranty conditions are neither extended nor restricted by any statements in this document.

The contents reflect the technical state at the time of printing.

We reserve the right to make technical changes in the course of further development.



WARNING

Use of a damaged or incomplete device

Risk of explosion!

- Do not use damaged or incomplete devices.

2.2 General safety information

Requirement for safe use

This equipment has been supplied from the factory in a totally safe condition. To maintain this condition and to ensure safe operation of the device, follow these instructions and observe all safety-relevant information.

Pay attention to the notices and symbols on the device. Do not remove any notices or symbols from the device. Keep the notices and symbols in a fully legible condition at all times.

2.3 Explanation of symbols and notices

This documentation contains notes that you must observe for your own personal safety and for the avoidance of damage to property. Notes concerning personal safety are highlighted by a warning triangle; notes concerning only damage to property are not marked by a warning triangle. Depending on the danger level, the warning notes are shown in decreasing order of severity as follows:



DANGER

means that death or serious injuries will occur if the corresponding preventive measures are not taken.



WARNING

means that death or serious injuries can occur if the corresponding preventive measures are not taken.



CAUTION

with a warning triangle means that slight injury and/or damage to property can occur if the corresponding preventive measures are not taken.



NOTICE

indicates an important item of information about the product itself or how the product should be handled, to which special attention should be paid.

CAUTION

without a warning triangle means that damage to property can occur if the corresponding preventive measures are not taken.

ATTENTION

indicates that an undesirable event or condition can occur if the corresponding instructions are not observed.

If several danger levels occur, the warning note for the respectively highest level will always be used. If a warning note with a warning triangle warns against personal injury, a warning against damage to property may be included in the same warning note.

2.4 Warning symbols on the device

Symbol	Explanation of the warning symbols on the device
	Observe the operating manual
	Protect the device against shocks (otherwise the protection class is not guaranteed)

2.5 Intended use

Observe the following:



WARNING

ARCA positioners may be used only for the applications specified in the associated technical documentation. Proper transport, storage, erection, assembly, installation, commissioning, operation and maintenance are required for trouble-free and safe operation. The permissible environmental conditions must be maintained. Notices in the associated documentation must be observed.



2.6 Improper modifications to the device

WARNING

Modification to the device

Modifications and repairs to the device, in particular in potentially explosive areas, can be dangerous for personnel, the plant and the environment!

- Modify or repair the device only as described in the instructions for the device. The manufacturer's warranty and the product approvals are rendered null and void if this is ignored.

2.7 Qualified Personnel

The device may be set up and operated only in conjunction with this documentation. Startup and operation may be performed only by **qualified personnel**. Qualified personnel within the meaning of the safety instructions in this documentation are persons who are authorised to commission, earth and mark devices, systems and circuits according to the safety standards.

Qualified persons are those who are familiar with the erection, assembly, startup and operation of the product. These persons possess the following qualifications:

- They are authorised and have been trained or instructed to operate and maintain devices and systems in accordance with the safety standards for electrical circuits, high pressures and aggressive and/or hazardous media.
- In the case of devices with explosion protection: they are authorised and have been trained or instructed to carry out work on electrical circuits for plants that are at risk from explosions.
- They have been trained or instructed in the care and use of appropriate safety equipment in accordance with safety standards.

2.8 Liability disclaimer

We have checked the contents of this manual for correspondence to the hardware and software described. Nevertheless, deviations cannot be ruled out; therefore we cannot give any guarantee for full correspondence. The details are checked regularly and any necessary corrections will be included in subsequent editions.

2.9 Laws and regulations

Observe the applicable test certificates, regulations, and laws in your country when connecting, installing, and operating the equipment.

These are, for example:

- IEC 60079-14 (international)
- EN 60079-14 (EC)
- Ordinance on Industrial Safety and Health (BetrSichV)

2.10 Conformity to directives

The applied standards can be found in the Declaration of Conformity for the device.

2.10.1 Conformity to European directives

The CE mark on the device indicates its conformity to the following European directives:

2014/30/EU EMC	Directive of the European Parliament and of the Council on the harmonisation of the Laws of the Member States relating to electromagnetic compatibility.
2014/34/EU ATEX	Directive of the European Parliament and of the Council on the harmonisation of the Laws of the Member States relating to equipment and protection systems intended for use in potentially explosive atmospheres.
2014/35/EU LVD	Directive of the European Parliament and of the Council on the harmonisation of the Laws of the Member States relating to the making available of electrical equipment designed for the use within certain voltage limits.

2.11 Use in potentially explosive areas



WARNING

Unsuitable device for potentially explosive areas

Explosion hazard!

- ▶ Use only devices that are approved for use in Ex-zones and are marked accordingly.
- ▶ Make sure that the device is suitable for the area of use.



WARNING

Loss of safety of the device in the ignition protection class Intrinsic Safety “Ex i”

If the device has already been operated on non-intrinsically safe circuits or with a higher operating voltage, the safety of the device for use in potentially explosive areas is no longer guaranteed. There is an explosion hazard!

- ▶ Connect the device in the ignition protection class Intrinsic Safety only to an intrinsically safe electrical circuit.
- ▶ Observe the electrical data in the certificate.

**⚠ WARNING****Impermissible accessories and impermissible spare parts**

Explosion hazard in potentially explosive areas or damage to the device!

- ▶ Use exclusively original accessories and original spare parts.
- ▶ Observe all relevant installation and safety instructions described in the manuals for the device, accessories and spare parts.

**⚠ WARNING****Open cable entry or incorrect cable gland**

Explosion hazard in potentially explosive areas or damage to the device!

- ▶ Seal the cable entries for electrical connections. Use only cable glands or blanking plugs that are approved for the specific ignition protection class.

**⚠ WARNING****Exceeding the maximum ambient or media temperature**

Explosion hazard in potentially explosive areas!

The temperature class of the device is no longer valid if the maximum permissible ambient or media temperature is exceeded!

- ▶ Make sure that the maximum permissible ambient or media temperature of the device is not exceeded.

**⚠ WARNING****Electrostatic charging of nameplates**

The nameplates used on the device can have a capacitance of up to 5 pF.

- ▶ Keep the device and cables away from strong electromagnetic fields.

**⚠ CAUTION****Electrostatic-Sensitive Assemblies**

The device contains electrostatically sensitive assemblies. Electrostatic-sensitive assemblies can be damaged by voltages far below the level detectable by humans. These voltages can occur when you touch a component or the electrical connections on an assembly without first discharging any static electricity. Damage caused by overvoltage may not be immediately apparent; it often becomes noticeable only after the assembly has been in operation for a longer period.

- ▶ Therefore, prevent electrostatic charging.

3 Transport, storage and packaging

3.1 Transport

Transport at a temperature lower than -40 °C or higher than +80 °C is not permissible.

3.2 Storage



NOTICE

Improper storage!

There is a danger of the product no longer functioning if it is stored improperly.

- Storage at a temperature lower than -40 °C or higher than +80 °C is not permissible.
- It must be stored in roofed-over storage places and that are weather-proof.

Openings are sealed with suitable means to prevent the ingress of dirt. These should be removed by technical personnel at the place of installation.



⚠ CAUTION

Inadequate protection during storage

The packaging offers only limited protection against moisture and infiltration!

- Provide additional packaging if necessary.

3.3 Packaging

The product is packed in a PE film inside the outer packaging (cardboard box, wooden crate, pallet, lattice box).

If the packaging, in particular the PE film, has been opened, the product must be stored immediately in a heated room.

The product must be packed in weatherproof or seaworthy packaging for transport by ship, rail or truck.

4 Type plate




Illustration 2: 827A nameplate

1	Manufacturer
2	Device name
3	Type
4	Observe the operating manual
5	Protection class
6	Auxiliary power (air supply)
7	Approvals
8	Marking for potentially explosive areas
9	Nominal signal range
10	Fabrication number

5 Type key

827A.	E	2	-	A	0	H	-	M	1	0	-	G	-	LT
[1]	[2]	[3]	-	[4]	[5]	[6]	-	[7]	[8]	[9]	-	[10]	-	[11]

1. Series

827A.	
-------	--

2. Explosion protection

E	without
X	Ex i (IS)

3. Basic device connection

2	2-wire
---	--------

4. Optional Modules

0	without
A	with Analog Output Module (AOM)

5. Limit monitor

0	Without
D	Digital I/O Module (DIO-2)
I	Inductive Limit Switches (ILS-2)
M	Mechanic Limit Switches (MLS-2)
B	Binary module (DIO)
S	Slot-type initiator module (ILS)
K	Contact module (MLS)

6. Communication

0	without communication
H	HART
P	PROFIBUS PA
F	Foundation Fieldbus

7. Housing material

A	Aluminum (single- and double-acting)
E	Stainless steel
M	Aluminum (single-acting only)

8. Pneumatics

1	single-acting
2	double-acting

9. Position detection

0	Standard (mechanical actuator)
1	with internal NCS module
2	without (AIM Module)

10. Connecting thread electrical/pneumatic

G	M20x1.5 / G 1/4
N	1/2" NPT / 1/4" NPT
M	M20x1.5 / 1/4" NPT
P	1/2" NPT / G 1/4
R	M12 plug for input signal / G 1/4
S	M12 plug for input signal / 1/4"-18 NPT

11. Options Z

FIP	Fail In Place
LT	- 40 °C
SA	M12 plug for Analog Output Module
SB	M12 plug for digital I/O module
SS	M12 plug for inductive limit switches
SW	M12 plug for NCS-sensor
NG	Operation with natural gas
BT	Bluetooth Adapter AW050

Example of type designation

827A.E2-A0H-M10-G-LT

Positioner 827A – without explosion protection – 2-wire connection – analog output module – without limit monitor – HART communication, aluminum housing – single-acting – standard mechanical actuator – connection threads: electrical M20x1.5 / pneumatic G 1/4 / -40 °C

6 Description

6.1 Function

- The electropneumatic positioner forms a control system when combined with an actuator. A servo potentiometer detects the actuator's current position and feeds it back as the actual value x . The setpoint and actual value are displayed simultaneously on the digital display.
- The setpoint w is determined by a current supplied to the positioner, which, during two-wire operation, also serves to power the positioner.
- The positioner operates as a predictive five-point controller, whose output magnitude $\pm\Delta y$ is converted to a pulse length modulated signal to operate the control valves.
- These control signals change the pressure in the actuator chamber(s), adjusting the actuator until the control error reaches zero.
- After removing the housing cover, three buttons and a digital display provide access to operation in manual mode and to configuration, including structuring, initialization, and parameterization.
- The basic device comes standard with one digital input (BE1). This digital input can be individually configured and used, for example, to block the operating levels.
- To accommodate a wide range of mechanically different rotary and linear actuators, the positioner features a slip clutch and a switchable transmission.

6.2 Construction

This section describes the mechanical and electrical construction, the device components and the principles of the positioner's operation.

The positioner is used to adjust and regulate pneumatic actuators. The positioner operates electro-pneumatically. Compressed air provides its auxiliary energy.

The positioner can be used, for instance, to regulate valves with:


- a linear actuator (Fig. 2) or
- a VDI/VDE 3845 rotary actuator (Fig. 3)

Linear actuators may be mounted in a number of ways.

- NAMUR or IEC 60534
- integrated mounting (ARCA, SAMSON)
- integrated mounting according to VDI/VDE 3847

The positioner can be mounted and operated on all normal actuators.

The device is available for single-acting and double-acting actuators as well as for potentially explosive and non-potentially explosive applications.



1	Actuator
2	Positioner, single-acting in metal housing
3	Yoke
4	Manometer block, single-acting
5	Valve


Illustration 3: Positioner mounted on a linear actuator (single-acting)



1	Positioner, double-acting, in stainless steel housing
2	Rotary actuator
3	Manometer block, double-acting

Illustration 4: Positioner mounted on a rotary actuator (double-acting)

6.3 Device Components



1	Supply air input
2	Output: actuating pressure Y1
3	Display
4	Output: actuating pressure Y2 *)
5	Operating Buttons
6	Restrictor Y1
6.1	Restrictor Y1 *)
6.2	Restrictor Y2 *)
7	Transmission ratio selector
8	Silencer
9	Slip clutch adjusting wheel
10	Basic device connecting terminals
11	Connecting terminals Option modules
12	Blinding plug
13	Cable gland
14	Clamping plate for cover
15	Purging air switch
*	with double/acting devices

Illustration 5: Construction

6.3.1 Motherboard

Located on the motherboard are:

- CPU
- Memory
- A/D converter
- Display
- Operating Buttons
- Connecting strips for the connection of the option modules to the motherboard.


6.3.2 Electrical Connections

The connecting terminals of the basic device as well as the analogue, binary and slot-type initiator module are located at the front left-hand edge and offset to each other in a staircase form.

An assembly cover secures the components against being pulled out, and prevents incorrect assembly.

6.3.3 Pneumatic Connections

The pneumatic connections are located on the right-hand side of the positioner.



1	Actuating pressure Y1 in single-acting and double-acting actuators
2	Feedback shaft
3	Air supply P_z
4	Actuating pressure Y2 on double-acting actuators
5	Exhaust air outlet E with silencer on the underside of the device

Illustration 6: Pneumatic connections

Connection variants

The following pneumatic connections are located at the rear of the positioner for the integrated fitting of single-acting linear actuators:

- actuating pressure Y1
- exhaust air outlet E

With the exception of the integrated ARCA fitting, these connections are sealed by screws.

The exhaust air outlet can be used for the blanketing of the sensing area and the spring chamber with dry, instrumentation-quality air to prevent corrosion.

Figure 6 illustrates the versions of the pneumatic connections for the various types of actuator, the positioning effect and the safety position after failure of the auxiliary power supply.



CAUTION

Note before working on the control valve

You must place the control valve in the safe position before working on it. Make sure that the control valve has reached the safe position. If you only interrupt the pneumatic auxiliary power to the positioner, it may take a certain time for the safe position to be reached.










Actuating pressure Connection	Actuator type	Safety position after auxiliary power failure			
		Electric	Pneumatic		
Y1		Closed 	Closed 	With part-turn actuators the counterclockwise direction of rotation - viewed on the actuating shaft of the valve - is defined as "Open". 	
Y1		Open 	Open 		
Y2		Open 	Last position (before auxiliary power failure)		
Y1		Closed 			
Y1		Closed	Closed		
Y1		Open	Open		
Y2		Open	Last position (before auxiliary power failure)		
Y1		Closed			


Illustration 7: Pneumatic connection positioning effect

6.3.4 Purging Air Switch

The purging air switch is accessible above the pneumatic connection strip on the valve block when the housing is open.

- In the IN position the interior of the housing is flushed by very small quantities of clean, dry instrumentation-quality air.

- In the OUT position, the purging air is fed directly outside.




- | | |
|---|----------------------------|
| 1 | Purging air switch |
| 2 | Pneumatic connection strip |

Illustration 8: Purging air switch on the valve block

6.3.5 Restrictors

The exhaust valve is always open in the de-energised state.

- In order to achieve actuating times of > 1.5 s with small actuators, it is possible to reduce the air flowrate by means of the restrictors Y1 and Y2.
- By turning to the right, the air power is reduced until it is completely blocked.
- In order to adjust the restrictors, it is recommended that they are closed and then slowly opened (see initialisation RUN3).
- Take care in the case of double-acting actuators that both restrictors are set approximately equal.



- | | |
|---|-------------------|
| 1 | 2.5 mm hex socket |
| 2 | Y1 |
| 3 | Y2 |

Illustration 9: Restrictors

7 Assembly

7.1 Safety instructions for assembly

CAUTION

Improper installation

Improper installation can result in damage to the device, its destruction or the impairment of its function.

Ascertain that the device shows no visible signs of damage each time before installing it.

Ascertain that the process connections are clean and that suitable seals and cable glands are used.

Install the device using suitable tools.



⚠ CAUTION

Mechanical impact effect

It is essential that the following sequence is observed during installation in order to avoid injury or mechanical damage to the positioner/mounting kit:

- ▶ Mount mechanically the positioner
- ▶ Connect the pneumatic auxiliary energy
- ▶ Connect the auxiliary electrical energy supply
- ▶ Carry out the commissioning procedure

ATTENTION

The device protection class becoming null and void

Damage to the device due to open or improperly closed housing. The protection class specified on the nameplate is no longer guaranteed.



⚠ CAUTION

Humid environment/dry compressed air

If the environment is humid, mount the positioner in such a way that there is no chance of the positioner axle freezing (getting stuck) at low ambient temperatures.

Make sure that water does not enter an open housing or screw connection. If the positioner cannot be immediately and permanently mounted and connected on site, it is possible for water to enter.

In general, only dry compressed air may be used to operate the positioner. Also refer to the chapter [13] *Technical Data*. You should therefore make use of the usual water separators. In extreme cases it may be necessary to use an additional dryer. The use of dryers is particularly important if you operate the positioner at low ambient temperatures. When mounting on the valve block, set the purging air switch above the pneumatic connections to the "OUT" position.

7.2 Mounting a linear actuator

7.2.1 Mounting with mounting kit for "Integrated Fitting Linear Actuator"

Included with the "integrated fitting linear actuator" are (see figures below for serial numbers):

Serial no.	No. of items	Name	Note
1	1	Driver pin cpl. with roller	mounted on lever (2)
2	1	Lever	
3	1	Washer	B6.4 - DIN 125 - A2
4	1	Spring lock washer	A6 – DIN 127- A2
5	1	Cylinder screw	M6 x 25 - DIN 7984 - A2
6	1	Hex nut	M6 - DIN 6923 – A2
7	1	Square nut	M6 - DIN 557 - A4
8	2	Cylinder screw	M8 x 65 - DIN 912 - A2
9	2	Spring lock washer	A8 - DIN 127 - A2
10	1	Screw plug	R1/4 – DIN 906 – A4
11	1	O-ring	13 x 2.5

Mounting procedure (see figures below)

1. Fig. 10: Adjust the pin (1) on the previously assembled lever (2) to the value of the stroke range given on the actuator or, if this is not available as a scale value, to the next larger scale value. In case of uncertainty with regard to the actual working stroke (pneumatic actuators often have a setting distance reserve), the next larger scale value should be selected. The centre of the pin should rest on the scale line on the lever (2). The same value can be set later during the commissioning under the parameter "3.YWAY", in order to display the setting distance in mm after the initialisation.
2. Fig. 11: Push the lever (2) to the stop on the positioner axle, and fix it with cylinder screw (5).
3. Open the rear actuation pressure outlet by removing the screw (12) and the O-ring (13).
4. When fitting with spring chamber exhaust air ventilation open the exhaust air outlet by removing the screw (14) and the O-ring (15).
5. Fig. 12: Seal the actuation pressure outlet with screw plug (10). When fitting with exhaust air ventilation remove exhaust air silencer and seal.
6. Insert the O-ring (11) in the yoke recess.
7. Locate the positioner on the actuator in such a way that the roller passes between the pins (16).
8. Align the positioner horizontally at the yoke, and assemble it with the screws (8) and spring lock washers (9).


**Assembly procedure plan -
integrated fitting**

Illustration 10: Lever mounted




Illustration 11: Mounting the lever on the positioner




Illustration 12: Mounting the positioner on the actuator

7.2.2 Mounting with mounting kit "Linear actuator IEC 60534"

Included with the mounting kit "Linear actuator IEC 60534", stroke 3 to 35 mm, are (see figures below for serial numbers):

Serial no.	No. of items	Name	Note
1	1	Driver pin cpl. with roller	mounted on lever (2)
2	1	NAMUR lever	For stroke range 3 mm to 35 mm, or (order separately for stroke range > 35 mm to 130 mm, see Fig. 13)
3	2	Washer	B 6.4 - DIN 125 - A2
4	3	Spring lock washer	A6 - DIN 127 - A2
5	3	Cylinder screw	M6 x 25 - DIN 7984 - A2
6	1	Hex nut	M6 - DIN 6923 - A2
7	1	Square nut	M6 - DIN 557 - A4
9	6	Spring lock washer	A8 - DIN 127 - A2
17	1	NAMUR mounting bracket IEC 60534	Standardised connecting location for mounting bracket with rib, column or flat surface
18	1	Sensing hoop	Guides the roller with the driver pin and turns the lever arm
19	2	Clamping piece	Assembly of the sensing hoop to the actuator's stem
20	2	U-bolts	Only for actuators with columns
21	2	Hex screw	M8 x 16 - DIN 933-A2
22	6	Washer	B 8.4 - DIN 125 - A2
23	4	Hex screw	M8 x 20 - DIN 933-A2
24	4	Hex nut	M8 - DIN 934 - A4

Mounting procedure (see figures below)

1. Fig. 14: Assemble the clamping pieces (19) using the cylinder screws (5) and spring lock washers (4) to the actuator stem.
2. Push the sensing hoop (2) into the cut-outs in the clamping piece. Adjust to the required length, and tightened the screws so that it is still just possible to push the sensing hoop.
3. Fig. 15: Adjust the pin (1) on the previously assembled lever (2) to the value of the stroke range given on the actuator or, if this is not available as a scale value, to the next larger scale value. In case of uncertainty with regard to the actual working stroke (pneumatic actuators often have a setting distance reserve), the next larger scale value should be selected. The centre of the pin should rest on the scale line on the lever (2). The same value can be set later during the commissioning under the parameter "3.YWAY", in order to display the setting distance in mm after the initialisation.
4. Push the lever (2) to the stop on the positioner axle, and fix it with cylinder screw (5).
5. Fig. 16: Mount the mounting bracket (17) to the rear of the positioner with two hex screws (21), spring lock washer (9) and washers (22). The choice of the row of holes depends on the width of the actuator's lantern width. The roller should engage in the sensing hoop (18) as close to the stem as possible, but must not touch the clamping pieces (19).
6. Fig. 17: Hold the positioner with the fixing angle to the actuator in such a way that the pin (1) passes inside the sensing hoop (18).
7. Tighten the sensing hoop (18).
8. Prepare the assembly parts in accordance with the actuator type:
 - Actuator with a rib: hex screw (23), washer (22) and spring lock washer (9).
 - Actuator with a flat surface: four hex screws (23) with washer (22) and spring lock washer (9).
 - Actuator with columns: two U-bolts (20), four hex nuts (24) with washer (22) and spring lock washer (9).
9. Attach the positioner with the previously prepared assembly parts to the yoke. Adjust the height of the positioner so that the horizontal position of the lever is achieved as close as possible to the centre of the stroke. The actuator's lever scale provides orientation here. It is essential that the horizontal lever position is passed through within the stroke range.




Illustration 13: NAMUR lever 3 mm to 35 mm (1), NAMUR lever > 35 mm to 130 mm (2)

Assembly procedure - linear actuator IEC




Illustration 14: Mounting the feedback lever on the actuator stem




Illustration 15: Lever mounted




Illustration 16: Mounting the NAMUR mounting bracket




Illustration 17: Fastening to different types of yoke

7.3 Mounting with mounting kit "Rotary actuator VDI/VDE 3845"

Included with the mounting kit "Rotary actuator VDI/VDE 3845", are (see figures below for serial numbers):

Serial no.	No. of items	Name	Note
3	1	Washer	B6.4 - DIN125 - A2
25	1	Coupling wheel	Mounting on the axle of the positioner
26	1	Driver	Fitted to the actuator's shaft stub
27	1	Labels	Display of the actuator position, consisting of scale and pointer
	8	Scale	Various divisions
	1	Pointer	Reference point for scale
28	4	Hex screw	M6 x 12 - DIN933 - A2
29	4	Lock washer	S6
30	1	Cylinder screw	M6 x 12 - DIN84 - A2
31	1	Mounting bracket VDI/VDE3845	
32	1	Square nut	M4 - DIN562 -A2
33	1	Hexagon socket screw	M4 x 10 - DIN916 - A2
34	1	Allen key	for item 33

Mounting procedure (see figures below)

1. Fig. 18: Attach the VDI/VDE 3845 mounting bracket (31), actuator-specific, supplied by actuator manufacturer, to the rear of the positioner, and fix it in place with the hex screws (28) and lock washers (29).
2. Insert square nut (32) into the coupling wheel (25), screw the hexagon socket screw (33) into the square nut (32).
3. Fig. 19: Push the coupling wheel (25) as far as it will go on the positioner axle, pull it back about 1 mm and tighten the hexagon socket screw (33) with the supplied Allen key (34).
4. Fig. 20: Place the driver (26) on the actuator's shaft stub and tighten it with cylinder screw (30) and washer (3).
5. Fig. 21: Carefully place the positioner with the mounting bracket on the actuator. One of the two pins (35) of the coupling wheel (25) must engage in the driver (26). You do not need to adjust the slip clutch if you use the pins (35) as described below. Commissioning is simplified as a result. There is a notch in each of the two pins (35) - see the following diagrams. Use the pin in which the notch has a V-shape (B) for actuators that close in a clockwise direction. Use the pin in which the notch has a rectangular shape (A) for actuators that open in a clockwise direction.
6. Fig. 22: Align the positioner / mounting bracket centrally on the actuator and screw tight (screws are not included with the supply, but are part of the actuator's mounting bracket!).


Assembly procedure for VDI/VDE 3845 rotary actuator

Illustration 18: Mounting the positioner on the bracket




Illustration 19: Mounting the coupling wheel on the positioner




Illustration 20: Mounting the driver on the actuator





Illustration 21: Mounting the positioner on the actuator





Illustration 22: Positioner with mounting bracket fitted on rotary actuator



- 1 Positioner fixing plane
- 2 Rotary actuator

Illustration 23: Mounting bracket (supplied by the actuator manufacturer) and dimensions

7.4 Use of positioners in humid environment

CAUTION

Never clean the positioner with a high pressure cleaner. Protection class IP 66 is inadequate for this.

This information provides you with important notes on mounting and operating the positioner in wet environments (frequent heavy rain and/or persistent tropical condensation) in which protection class IP66 is no longer sufficient, in particular when there is a risk that the water might freeze.

Avoid unfavourable installation positions:

- in order to prevent the penetration of liquids into the device, e.g. through the exhaust air openings, during normal operation.
- As the digital display is otherwise difficult to read.




Illustration 24: Favourable and unfavourable installation positions

If local conditions force you to operate the positioner in an unfavourable installation position, you can prevent the entry of water through additional measures.

Additional measures

The additional steps necessary to prevent the entry of water depends on the installation position chosen. In certain cases you may need:

- Threaded joint with sealing rings (e.g. FESTO: CK -1/4 -PK-6)
- Plastic hose, approx. 20 to 30 cm (e.g. FESTO: PUN- 8X1.25 SW)
- Cable ties (number and length depend on the local conditions)

Procedure

1. Assemble the piping in such a way that rainwater or condensation that runs along the length of the pipes can drip off before reaching the positioner's connection strip.
2. Check that the seals for the electrical connections are correctly seated.
3. Check that the seal of the housing cover is not damaged or soiled. Clean or replace it if necessary.
4. If possible, mount the positioner in such a way that the sintered bronze silencer on the underneath of the housing is pointing downwards (vertical installation position). If this is not possible, the silencer should be replaced by a plastic hose using a suitable threaded joint.

Assembling the threaded joint with plastic hose

1. Unscrew the sintered bronze silencer from the exhaust air opening on the underside of the housing.
2. Screw the threaded joint mentioned above into the outlet opening.
3. Fit the plastic hose mentioned above to the threaded joint and check that it is tightly seated.
4. Use a cable tie to fasten the plastic hose to the fittings in such a way that the opening is pointing downwards.
5. Check that the hose is not kinked, and that the exhaust air can flow out easily.

8 Electrical connection

Basic safety instructions



WARNING

Incorrect power supply

Danger of explosion in potentially explosive areas if the power supply is incorrect, e.g. if alternating current is used instead of direct current.

- ▶ Connect the device in accordance with the prescribed supply and signal circuits. The applicable regulations can be found in the certificates or on the type plate.



WARNING

Unsafe low-voltage power supply

Danger of explosion in potentially explosive areas due to voltage flashover.

- ▶ Connect the device to a low-voltage power supply with safe isolation.



WARNING

Connection of the device when live

Risk of explosion in potentially explosive areas

- ▶ Connect the device in potentially explosive areas only when switched off.

⇒ **Exceptions:** energy-restricted circuits may be connected in potentially explosive areas even when live.



WARNING

Missing potential equalisation

If there is no potential equalisation, there is a danger of explosion in potentially explosive areas due to equalising current or ignition functions.

- ▶ Make sure that potential equalisation is available for the device.

⇒ **Exceptions:** in the case of devices with the ignition protection class Intrinsic Safety "Ex i" it may be possible to dispense with potential equalisation.



WARNING

Unprotected wire ends

Danger of explosion in potentially explosive areas due to unprotected wire ends.

- ▶ Protect unused wire ends according to IEC/EN 60079-14.



⚠ WARNING

Improper routing of shielded cables

Danger of explosion due to equalisation currents between the potentially explosive area and areas that are not potentially explosive.

- ▶ Earth shielded cables leading into the potentially explosive area at one end only.
- ▶ In case of earthing at both ends, lay a potential equalisation conductor.



⚠ WARNING

Unsuitable cables and/or cable glands

Danger of explosion in potentially explosive areas and if cables and/or cable glands are connected that do not match each other or do not meet the technical requirements.

- ▶ Use only cables and cable glands that meet the specified requirements.
- ▶ Tighten the cable glands according to the specified torques.
- ▶ When replacing cable glands, use only cable glands of the same type.
- ▶ Check the tightness of the cables after installation.

CAUTION

Formation of condensation in the device

Damage to the device due to the formation of condensation if the temperature difference between transport or storage and the place of installation is more than 20 °C.

- Leave the device to stand for a few hours in the new environment before putting it into operation.

CAUTION

Excessively high ambient temperature

Damage to the cable insulation.

- If the ambient temperature is ≥ 60 °C, use heat-resistant cables designed for an ambient temperature at least 20 °C higher.

CAUTION

Connection of a voltage source to a current input

Damage to the device if a voltage source is connected to the current input I_w (terminals 6 and 7).

- Never connect the current input I_w to a voltage source, otherwise the positioner can be destroyed.
- Always use a current source with a maximum output current I of 20 mA.



⚠ WARNING

"Ex i" version

Only certified, intrinsically safe electrical circuits may be connected as auxiliary power, control or signal circuits.

For reasons of tightness (IP housing protection class) and the necessary tensile strength, use only cables with diameter of ≥ 8 mm (or a suitable sealing insert in the case of smaller cable diameters) with the standard cable gland M20x1.5.

In the NPT version the positioner is supplied with an adaptor. Make sure when inserting a mating part in the adaptor that the maximum permissible torque of 10 Nm is not exceeded.

2-wire operation

To maintain the auxiliary power, the input current I_w must be 3.6 mA.

8.1 Electrical connection of basic device




Illustration 25: 2-wire connection 2-wire device

1 Area of no explosive hazard	4 Digital Input 1
2 Potentially explosive area	5 Signal source
3 Main electronic board	6 HART communicator




Illustration 26: Series connection of 2 positioners, e.g. split-range operation

1 Area of no explosive hazard	6 Device 2
2 Potentially explosive area	7 Positioning range 2
3 Device 1	8 Digital Input 2
4 Positioning range 1	9 Total positioning range I_y
5 Digital Input 1	10 Signal source
	11 Supply source

8.2 Electrical connection options

Analog Output Module (AOM)






Illustration 27: Analog Output Module (AOM)

1 Area of no explosive hazard	3 Position feedback module
2 Potentially explosive area	4 Supply isolator

**Binary I/O Module (DIO) or
digital I/O Module (DIO-2)**

Illustration 28: DIO / DIO-2 without explosion protection

1 Area of no explosive hazard	5 Fault signal
2 Potentially explosive area	6 Limit value
3 Digital I/O Module (DIO)	7 Switching amplifier
4 Digital input 2	8 Switch output


Illustration 29: DIO / DIO-2 in "Ex i" version

1 Area of no explosive hazard	5 Fault signal
2 Potentially explosive area	6 Limit value
3 Digital I/O Module (DIO)	7 Switching amplifier
4 Digital input 2	8 Switch output


**Slot-type initiator module (ILS)
or inductive limit switches
(ILS-2)**


Illustration 30: ILS / ILS-2

1 Area of no explosive hazard	4 Fault signal
2 Potentially explosive area	5 Limit value
3 Inductive limit switches	6 Switching amplifier

**Contact module (MLS) or
Mechanic Limit Switches
(MLS-2)**

⚠ WARNING
Protection against mechanical influences

To maintain the IP66 rating, protect the module from mechanical damage. Do this by selecting a suitable installation location or installing an appropriate protective guard. This protection requirement applies when the module operates at the following voltages:

- ▶ > AC 16 V
- ▶ > DC 35 V, low voltage

ATTENTION
Maximum values of terminals 41/42 and 51/52 - "Ex i" version

The following maximum values apply only to terminals 41 and 42 and to terminals 51 and 52:

- Maximum voltage: 30 V DC
- Maximum current: 100 mA DC
- Maximum power: 750 mW

The terminals are not safely isolated from one another.

ATTENTION
To be observed before installation and connection

- Exclusively qualified personnel are authorized to install and connect the contact module.
- Disconnect all cables from sources of electricity and check that they are really de-energized.
- Select the cross-section of the connecting cables so that it corresponds to the permissible current load.


- Select the cables according to the following rule: The wires' rated operating temperature must be at least 25 °C higher than the maximum ambient temperature.
- Operate the Ex version only in intrinsically safe electrical circuits with approved switching amplifiers.

ATTENTION**Preparation of the cables or wires - "Ex i" version**

- Strip the wires so that the insulation is flush with the terminal when the wires are inserted.
- Use ferrules on stranded-wire ends.

Connecting MLS / MLS-2 (See Figure 36).

1. Loosen the screw (18) on the transparent cover (19).
2. Pull the clear cover (19) all the way to the front stop.
3. Screw each wire securely into the corresponding terminal.
4. Slide the transparent cover (19) to the stop on the motherboard.
5. Tighten the screw (18) on the transparent cover (19).
6. Fasten the cables for each switch in pairs to the circuit board tabs. Use the supplied cable ties (20) for this.



- | | |
|----|-----------|
| 18 | Screw |
| 19 | Cover |
| 20 | Cable tie |

Illustration 31: Cable fastening




Illustration 32: MLS / MLS-2

1 Area of no explosive hazard	5 Limit value
2 Potentially explosive area	6 Switching amplifier
3 Limit value - Mechanic Limit Switches	7 Switch output
4 Fault signal	

8.3 Optional version M12 plug

This section describes which terminal of the devices and option modules listed below is connected to which pin of the M12 plug.




Illustration 33: Pinout, connector side

Pin designation	Wire color M12 plug
1	brown
4	black
3	blue
2	white

M12 plug in the 2-wire basic device

Current input terminal	Pin designation
6 (+)	1 - brown
Housing shield connection	4 - black
7 and 8 (-)	3 - blue

M12 plug for Analog Output Module

Current input terminal	Pin designation
61 (+)	1 - brown
Housing shield connection	4 - black
62 (-)	3 - blue

M12 plug for digital I/O and Inductive Limit Switch Module

Digital output terminals	Pin designation
41 (+)	1 - brown
42 (-)	3 - blue
51 (+)	2 - white
52 (-)	4 - black

M12 plug for external displacement sensor

Terminal	Pin designation
GND (X1/1)	4 - black
POT (X1/2)	3 - blue
VREF (X1/3)	2 - white
VCC (X1/4)	1 - brown

9

Pneumatic connection**⚠ WARNING**

For reasons of safety, the auxiliary pneumatic energy should only be connected after assembly when, in the presence of an electrical signal, the positioner is switched to the P-manual operating level.

(Delivery status, see leaflet "Concise operating notes").

ATTENTION

Ensure correct air quality!

Oil-free, instrument air with no water or dust, solid material content max. 1 mg/m³ (standard atmospheric conditions), max. particle size 1 µm, oil content max. 0.1 mg/m³ (standard atmospheric conditions), pressurised dew point 20 K below the lowest ambient temperature.

When working on the compressed air system ensure that any contamination present such as water, oil, chips, soldering material residues, etc. are expelled by blowing out.

Procedure:

1. If appropriate, connect manometer block for supply air and actuation pressure.
2. Connection via internal thread:
 - P_z: Supply air 1.4 to 7 bar
 - Y1: Actuation pressure 1 for single-acting and double-acting actuators
 - Y2: Actuation pressure 2 for double-acting actuators
 - E: Exhaust air output (remove silencer if necessary)
3. Safety position at failure of auxiliary electrical energy:
 - Single-acting: Y1 = vented
 - Double-acting: Y1 = max. actuation pressure (supply air pressure)
 - Double-acting: Y2 = vented
4. Connect actuation pressure Y1 or Y2 (double-acting actuators only) according to the desired safety position.
5. Connect supply air to P_z.

So that spring-loaded pneumatic actuators can reliably exploit the maximum possible setting distance, it is necessary that the supply pressure exceeds the maximum required final pressure of the actuator by a sufficient margin.

Check the leak-tightness of the entire pipeline after mounting the pneumatic connections. Apart from constant consumption of air, a leak results in the positioner constantly trying to correct the position deviation. The consequence is premature wear of the entire control device.

10 Commissioning

See leaflet "Concise operating notes"!



WARNING

Improper commissioning in potentially explosive areas

Failure of device or risk of explosion in potentially explosive areas

- ▶ Do not put the device into operation until it is completely assembled and connected.
- ▶ Consider the effects on other devices in the plant before commissioning.



WARNING

Loss of the explosion protection

Risk of explosion in potentially explosive areas due to open or improperly closed device.



WARNING

Opening the device when live

Risk of explosion in potentially explosive areas

- ▶ Open the device only when it is switched off.
 - ▶ Before commissioning, check that the cover, the cover fastenings and the cable glands have been fitted properly.
- ⇒ **Exceptions:** devices of the ignition protection class Intrinsic Safety "Ex i" may also be opened in a potentially explosive area when switched on.



WARNING

Water in the compressed air line

Device damage and possible loss of the ignition protection class. The purging air switch is factory-preset to "IN". In the "IN" position, water from the compressed air line can get into the device through the pneumatics during the initial commissioning.

- ▶ Before commissioning, make sure that there is no water in the compressed air line.
- ⇒ If you cannot be sure that there is no water in the compressed air line:
- ▶ Switch the purging air switch to "OUT". This prevents water from the compressed air line getting into the device.
 - ▶ Set the purging air switch back to "IN" only after all the water has been removed from the compressed air line.

ATTENTION

The device protection class becoming null and void

Damage to the device due to open or improperly closed housing. The protection class specified on the nameplate is no longer guaranteed.



- Make sure that the device is securely closed.

WARNING

Commissioning and operation in case of an error message

If an error message is displayed, the proper operation in the process is no longer guaranteed.

- ▶ Check the severity of the error.
- ▶ Rectify the error.
- ▶ If an error occurs:
 - ⇒ Switch the device off.
 - ⇒ Prevent it from being switched on again.

ATTENTION

- During initialisation the operating pressure must be at least 1 bar greater than the pressure necessary to open or close the valve. However, the operating pressure may not be greater than the maximum permissible operating pressure of the actuator.
- The transmission ratio selector can only be adjusted when the positioner is open. Check, therefore, that this has been adjusted before closing the housing.

Safety instructions for operation with natural gas

As a requirement for operation with natural gas all inserted electronics of the ACAPRO 827A, including optional modules, must comply with the available safety requirements protection type "Ex ia" and an electric connection with protection level "ia".

Sufficient ventilation for this operating condition must be ensured to avoid a Zone 0 atmosphere around the device.

If you operate the positioner with natural gas, it is not permitted to use Contact module.

You must depressurize devices operated with natural gas adequately for maintenance work.

Open the lid in an explosion-free atmosphere and depressurize the device for at least two minutes.

General information

Following the mounting of the positioner on a pneumatic actuator, the positioner must be supplied with pneumatic and electrical auxiliary energy.

Before the initialisation the positioner is in the operating mode "P-manual operation". "NOINI" flashes in the lower line of the digital display.

The positioner is matched to the respective actuator through the initialisation procedure and the setting of parameters. If necessary, the matching of the positioner to the actuator can be undone with the "PRST" parameter. Before this procedure the positioner is once again in the operating mode "P-manual operation".

Initialisation modes

- Automatic initialisation

The initialisation takes place automatically. In this case, the positioner determines, one after another, the effective working direction, the stroke or rotation angle and the actuator's adjustment times and adjusts the control parameters to match the dynamic behaviour of the actuator.

- **Manual initialisation**

The stroke or rotation angle of the actuator is set manually. The other parameters are automatically determined, just as in the case of automatic initialisation. You need this function in the case of "soft" end stops.

- **Copying Initialisation Data (Positioner Exchange)**

The initialisation of a positioner can be read out and loaded to another positioner. This allows a faulty device to be exchanged, without having to interrupt a running process in order to carry out initialisation.

You only have to provide a few parameters to the positioner before initialisation. Due to preset values you do not have to adapt any further parameters for the initialisation

The settings made can be protected against inadvertent change with a correspondingly parameterised and activated binary input.

10.1 Preparation for commissioning of linear actuators

- Fit the positioner using the appropriate mounting kit. The position of the transmission ratio selector in the positioner is particularly important here.

Stroke	Lever	Position of the transmission ratio selector
5 to 20 mm	short	33° (i.e. down)
25 to 35 mm	short	90° (i.e. up)
40 to 130 mm	long	90° (i.e. up)

- Connect a suitable current or voltage source.
- Connect the actuator and the positioner to the pneumatic lines, and activate the positioner's auxiliary pneumatic power.
- The positioner is now in the "**P-manual**" operating mode. The top line of the display now shows the current sensor voltage (P) in percent, e.g.: "**P37.5**", while "**NOINI**" flashes on the bottom line:



- Check that the mechanism can move freely across the entire active range by moving the actuator with the Δ and ∇ buttons to the respective end positions. The value must not drop below P5.0 or exceed P95.0. The difference between the two values must be greater than 25.0. You can quickly adjust the actuator by holding down one directional button and pressing the other directional button at the same time.
- Now move the actuator so that the lever is horizontal. The display should show a value between **P48.0** and **P52.0**.

10.1.1 Automatic initialisation of linear actuators

When you can move the actuator correctly, leave it in a central position and start the automatic initialization:

1. Press and hold the  button for more than 5 seconds. This will take you to the configuration mode. Display:



2. Press the  button briefly to switch to the second parameter, "YAGL". Display:



3. Use the  button to proceed to the next display:



You only need to set this parameter if you want the total stroke (in mm) displayed at the end of the initialization phase. To do this, select the same value on the display as the one you set for the driver pin on the scale at the lever.

4. Use the  button to proceed to the next display:



5. Start the initialization by pressing the  button for longer than 5 s. Display:



"RUN1" to "RUN5" appear in sequence in the lower display during the initialization process. Depending on the actuator, the initialization can take up to 15 minutes and is completed when the following display appears:



The first line also shows the measured stroke in millimeters if the lever length was specified using parameter "3.YWAY". Zeile steht zusätzlich der ermittelte Hub in mm, falls die eingestellte Hebellänge mit Parameter "3.YWAY" angegeben wurde.

The following display appears after briefly pressing the  button:



To exit **Configuration** mode, press and hold the  button for more than 5 seconds. After approximately 5 seconds, the software version is displayed. When the  button is released, the device will be in manual mode.

You can cancel an initialization in progress at any time by pressing the  button. Your previous settings will be retained. The parameters will only be reset to the factory settings after you have carried out a "Preset".

10.1.2 Manual initialisation of linear actuators

This function lets you initialize the positioner without driving the actuator hard against its end stops. The start and end positions of the setting distance are set manually.

When you can move the actuator correctly, leave it in a central position and start the manual initialization. The remaining initialization steps, including control-parameter optimization, run automatically as they do during automatic initialization.


1. Press and hold the  button for more than 5 seconds. This will take you to the configuration mode. Display:



2. Press the  button briefly to switch to the second parameter. Display:



or



3. Press the  button twice to move on to the following display:



4. Start the initialization by pressing the button for longer than 5 s.
Display:



5. After 5 s the display changes to:



Now use the and buttons to move the actuator to the position that you wish to define as the first of the two end positions. Then press the button. This will register the current position as end position 1, and will move on to the next step.

6. The following appears on the display:



Now use the and buttons to move the actuator to the position that you wish to define as the second end position. Then press the button. This saves the current position as end position 2.

7. The rest of the initialization will now proceed automatically. The bottom line of the display sequentially shows "RUN1" through "RUN5". When initialization is successfully completed, the following display appears:



The first line also shows the measured stroke in millimeters if the lever length was specified using parameter "3.YWAY". Zeile steht zusätzlich der ermittelte Hub in Millimetern, falls die eingestellte Hebellänge mit Parameter "3.YWAY" angegeben wurde.

Briefly press the button to return the bottom line of the display to "5.INITM". This returns you to configuration mode.

To exit configuration mode, press and hold the button for more than 5 seconds. After approximately 5 seconds, the software version is displayed. When the button is released, the device will be in manual mode.

10.2 Preparation for commissioning of rotary actuators

1. Fit the positioner using the appropriate mounting kit.
2. Connect a suitable current or voltage source.
3. Connect the actuator and the positioner to the pneumatic lines, and activate the positioner's auxiliary pneumatic power.
4. The positioner is now in **"P–Manual operating mode"**. The top line of the display now shows the current sensor voltage (P) in percent, e.g.: **"P37.5"** appears on the top line, while **"NOINI"** flashes on the bottom line:



5. Check that the mechanism can move freely across the entire active range by moving the actuator with the Δ and ∇ buttons to the respective end positions. The value must not drop below P5.0 or exceed P95.0. The difference between the two values must be greater than 25.0.

You can quickly adjust the actuator by holding down one directional button and pressing the other directional button at the same time.

10.2.1 Automatic initialisation of rotary actuators

When you can move the actuator correctly through its range, leave it in a central position and start the automatic initialization:

1. Press and hold the $\square$ button for more than 5 seconds. This will take you to the configuration mode. Display:



2. Use the ∇ button to set the parameter to "turn". Display:



3. Use the $\square$ button to proceed to the next display:



4. Start the initialization by pressing the Δ button for longer than 5 s
Display:



"RUN1" to "RUN5" appear in sequence in the lower display during the initialization process. Depending on the actuator, the initialization can take up to 15 minutes and is completed when the following display appears:



The upper value gives the actuator's full rotation angle (e.g. 93.5°). The following display appears after briefly pressing the  button:



To exit **Configuration** mode, press and hold the  button for more than 5 seconds. After approximately 5 seconds, the software version is displayed. When the  button is released, the device will be in manual mode.

You can cancel an initialization in progress at any time by pressing the  button. Your previous settings will be retained. The parameters will only be reset to the factory settings after you have carried out a "Preset".

10.2.2 Manual initialisation of rotary actuators

This function lets you initialize the positioner without driving the actuator hard against its end stops. The start and end positions of the setting distance are set manually.

When you can move the actuator correctly, leave it in a central position and start the manual initialization. The remaining initialization steps, including control-parameter optimization, run automatically as they do during automatic initialization.

1. Press and hold the  button for more than 5 seconds. This will take you to the configuration mode. Display:



2. Use the  button to set the "YFACT" parameter to "turn". Display:



3. Press the  button briefly to switch to the second parameter. Display:



4. Press the  button twice to move on to the following display:



The following steps are identical to steps 5 to 8 in the initialization of linear actuators.

After successful initialization, the determined pivoting range is shown in degrees on the upper display.

Briefly press the  button to return the bottom line of the display to "5.INITM". This returns you to configuration mode.

To exit configuration mode, press and hold the  button for more than 5 seconds. After approximately 5 seconds, the software version is displayed. When the  button is released, the device will be in manual mode.

10.3 Copying Initialisation Data (Positioner Exchange)

- Electropneumatic positioners can be replaced while the plant is running, without interrupting the process.
- By copying and transferring the device and initialization data, you can commission a replacement positioner without initializing it first.
- The electropneumatic positioner uses the communication interface for data transmission.

The following steps are required to exchange a positioner:

1. Use SIMATIC PDM or a HART communicator to import and save the device parameters and initialization data (determined during initialization) of the device to be replaced. This step is not necessary if the device has been parameterized with SIMATIC PDM and the data has already been saved.
2. Fix the actuator in its current position (mechanically or pneumatically).
3. Read and note the current position value from the display of the positioner that is being replaced. If the electronics are defective, determine the current position by measuring at the actuator or valve.
4. Remove the positioner. Install the positioner's lever arm on the replacement unit. Install the replacement unit on the valve. Put the transmission ratio selector in the same position as on the faulty device. Download the device data and initialization data from the SIMATIC PDM or the HART communicator.
5. The positioner is now ready for operation.

The accuracy and the dynamic behavior may not be as good as they would be following a proper initialization. In particular, the positions of the hard end stops and the associated maintenance data may differ. Therefore, initialize the positioner at the next available opportunity.

ATTENTION

Subsequent initialization

Initialize the replacement positioner as soon as possible. Only through initialization can you ensure the following properties:

- Optimal positioner adjustment to the actuator's mechanical and dynamic characteristics
- Unrestricted accuracy and unrestricted dynamic behavior of the positioner
- Non-deviating positions of the hard stops
- Correctness of the maintenance data

11 Parameter overview

11.1 Parameters 1 to 5

Parameters 1 to 5 are the same for all versions of the positioner. Use these parameters to adapt the positioner to the actuator. In most cases, setting these parameters is sufficient to operate the positioner with an actuator.

To learn how the positioner works in detail, systematically test the effects of the remaining parameters one at a time.

Paramet-ers	Function	Parameter values (bold = factory setting)			Unit
1.YFCT	Actuator type		Normal	Inverted	
		Rotary actuator	turn	-turn	
		Linear actuator	WAY	-WAY	
		Linear actuator without sine correc-tion	LWAY	-LWAY	
		Rotary actuator with NCS	ncSt	-ncSt	
		Linear actuator with NCS	ncSL	- ncSL	
		Linear actuator with NCS and lever	ncSLL	-ncSLL	
2.YAGL	Nominal rotation angle of the feedback				°
		33°			
		90°			
3.YWAY	Stroke range (optional setting) ▪ Parameter appears only with "WAY" and "ncSLL" ▪ If used, the value must correspond to the stroke range set on the actuator. Set the driver to the actuator stroke value or, if the stroke is not scaled, to the next larger scaled value.)				OFF
	5 10 15 20 (short lever 33°)				mm
	25 30 35 (short lever 90°)				
	40 50 60 70 90 110 130				
	(long lever 90°)				
4.INITA	Initialization (automatic)	NOINI no / ###.# Strt			
5.INITM	Initialization (manual)	NOINI no / ###.# Strt			

11.2 Parameters 6 to 52

The following auxiliary positioner functions are set with these parameters:

- Setpoint conditioning
- Actual value conditioning
- Digital signal processing
- Sealing function
- Limit value detection

Parameters	Function	Parameter values (bold = factory setting)	Unit
6.SCUR	Setpoint current range		
	0 ... 20 mA	0 mA	
	4 ... 20 mA	4 mA	
7.SDIR	Setpoint setting		
	Rising	riSE	
	Falling	FALL	
8.SPRA	Setpoint split range start	0.0 ... 100.0	%
9.SPRE	Setpoint split range end	0.0 ... 100.0	%
10.TSUP	Setpoint ramp UP	Auto / 0 ... 400	s
11.TSDO	setpoint ramp DOWN	0 ... 400	s
12.SFCT	Setpoint function		
	Linear	Lin	
	Equal per-centage	1 : 25	1 - 25
		1 : 33	1 - 33
		1 : 50	1 - 50
	Inverse equal percentage	25 : 1	n1 - 25
		33 : 1	n1 - 33
		50 : 1	n1 - 50
	Freely adjustable	FrEE	
13.SL0 ... 33.SL20	Setpoint interpolation point (interpolation points appear only if 12.SFCT = "FrEE" is selected)		
13.SL0	at 0 %		
14.SL1	5 % ...	0.0 ... 100.0	%
32.SL19	95 %		
33.SL20	100 %		
34.DEBA	Controller dead zone	Auto / 0.1 ... 10.0	%
35.YA	Control value limitation Start	0.0 ... 100.0	%
36.YE	Control value limitation End	0.0 ... 100.0	%
37.YNRM	Control value normalization		
	to mechanical path	MPOS	
	to flow	FLOW	
38.YDIR	Direction of action of control value for display and position feedback		

	Rising	riSE	
	Falling	FALL	
39.YCLS	Control value - tight closing/- fast closing		
	Without	no	
	Tight closing, top	uP	
	Tight closing, bottom	do	
	Tight closing, top and bottom	uP do	
	Fast closing, top	Fu	
	Fast closing, bottom	Fd	
	Fast closing, top and bottom	Fu Fd	
	Tight closing, top and fast closing, bottom	uP Fd	
	Fast closing, top and tight closing, bottom	Fu do	
40.YCDO	Value for tight closing below	0.0 ... 0.5 ... 100	%
41.YCUP	Value for tight closing above	0.0 ... 99.5 ... 100	%
42.BIN1	Function of digital input BE1	NO contact (action in case of closed switch or high level)	normally closed (action in case of open switch or low level)
	Without	OFF	
	Message only	on	-on
	Block configuration	bloc1	
	Block configuration and manual	bloc2	
	Move valve to YE position	uP	-uP
	Move valve to YA position	doWn	-doWn
	Block movement	StoP	-StoP
	Partial stroke test	PST	-PST
43.BIN2	Function of digital input BE2	NO contact (action in case of closed switch or high level)	normally closed (action in case of open switch or low level)
	Without	OFF	
	Message only	on	-on
	Move valve to YE position	uP	-uP
	Move valve to YA position	doWn	-doWn
	Block movement	StoP	-StoP
	Partial stroke test	PST	-PST

44.AFCT	Alarm function	Normal (High level with no error)	Inverted (Low level with no error)	
	Without	OFF		
	A1 = Min, A2 = Max			
	A1 = Min, A2 = Min			
	A1 = Max, A2 = Max			
45.A1	Response threshold alarm 1	0.0 ... 10.0 ... 100		%
46.A2	Response threshold alarm 2	0.0 ... 90.0 ... 100		%
47. FCT	Fault signal output function ("+" means: Logical OR operation)	Normal (High level with no error)	Inverted (Low level with no error)	
	Fault			
	Fault + not automatic			
	Fault + not automatic + BE			
	48. TIM	Monitoring time for setting the "control deviation" error message	Auto / 0 ... 100	
49. LIM	Response threshold for the "control deviation" error message	Auto / 0 ... 100		%
50.PRST	Preset			
	Resetting of all parameters that can be reset with "Init", "PArA" and "diAg"	ALL		
	Resetting of the initialization parameters 1.YFCT to 5.INITM.	Init		
	Resetting of the parameters 6.SCUR to 49.LIM.	PArA		
	Resetting parameters A to P of the extended diagnostic function as well as parameter 52.XDIAG	diAg		
51.PNEUM	pneumatic type			
	Standard valve block	Std		
	Fail-in-place valve block	FIP		
	Operation with booster	booSt		
52.XDIAG	Activation of the extended diagnosis			
	Parameters A to P are displayed only if the parameter was activated with On1, On2 or On3. The contents of parameters A through P are also displayed only if the corresponding parameter has been set to "On".			
	Off	OFF		
	Single-step message	On1		

	Two-step message	On2	
	Three-step message	On3	

11.3 Parameters A to P

The expected diagnostic function of the positioner is set with these parameters.

Parameters A to P and their sub-parameters are displayed only if the extended diagnosis was activated by parameter "XDIAG" with the parameter value "On1", "On2" or "On3".

Parameters	Function	Parameter value (bold = factory setting)	Unit
A.  PST	Partial stroke test with the following parameters:		
A1.STPOS	Start position	0.0 ... 100.0	%
A2.STTOL	Start tolerance	0.1 ... 2.0 ... 10.0	%
A3.STRKH	Travel height	0.1 ... 10.0 ... 100.0	%
A4.STRKD	Stroke direction	uP / do / uP do	
A5.RPMD	Ramp mode	OFF / On	
A6.RPRT	Ramp rate	0.1 ... 1.0 ... 100.0	%/s
A7.FLBH	Behaviour after failed PST	Auto / Hold / AirIn / AirOu	
A8.INTRV	Test interval	OFF / 1 ... 365	d
A9.PSTIN	Partial stroke test reference jump time	NOINI / (C)##.# / Fdini / rEAL	s
AA.FACT1	Factor 1	0.1 ... 1.5 ... 100.0	
Ab.FACT2	Factor 2	0.1 ... 3.0 ... 100.0	
AC.FACT3	Factor 3	0.1 ... 5.0 ... 100.0	
b.  DEVI	General valve error with the following parameters:		
b1.TIM	Time constant	Auto / 1 ... 400	s
b2.LIMIT	Limit value	0.1 ... 1.0 ... 100.0	%
b3.FACT1	Factor 1	0.1 ... 5.0 ... 100.0	
b4.FACT2	Factor 2	0.1 ... 10.0 ... 100.0	
b5.FACT3	Factor 3	0.1 ... 15.0 ... 100.0	
C.  LEAK	Pneumatic leak with the following parameters:		
C1.LIMIT	Limit value	0.1 ... 30.0 ... 100.0	%
C2.FACT1	Factor 1	0.1 ... 1.0 ... 100.0	
C3.FACT2	Factor 2	0.1 ... 1.5 ... 100.0	
C4.FACT3	Factor 3	0.1 ... 2.0 ... 100.0	
d.  STIC	Static friction (stick-slip effect) with the following parameters:		
d1.LIMIT	Limit value	0.1 ... 1.0 ... 100.0	%
d2.FACT1	Factor 1	0.1 ... 2.0 ... 100.0	
d3.FACT2	Factor 2	0.1 ... 5.0 ... 100.0	
d4.FACT3	Factor 3	0.1 ... 10.0 ... 100.0	
E.  DEBA	Dead-zone monitoring with the following parameters:		
E1.LEVEL3	Threshold	0.1 ... 2.0 ... 10.0	%

F. 	ZERO	Zero-point shift with the following parameters:			
F1.LEVEL1	Threshold 1	0.1 ... 1.0 ... 10.0	%		
F2.LEVEL2	Threshold 2	0.1 ... 2.0 ... 10.0	%		
F3.LEVEL3	Threshold 3	0.1 ... 4.0 ... 10.0	%		
G. 	PEN	Shift of the upper stop with the following parameters:			
G1.LEVEL1	Threshold 1	0.1 ... 1.0 ... 10.0	%		
G2.LEVEL2	Threshold 2	0.1 ... 2.0 ... 10.0	%		
G3.LEVEL3	Threshold 3	0.1 ... 4.0 ... 10.0	%		
H. 	TMIN	Monitoring of the lower limit temperature with the following parameters:			
H1.TUNIT	Temperature unit	°C	°F	°C/°F	
H2.LEVEL1	Threshold 1	-40 ... -25 ... 90	-40 ... 194		
H3.LEVEL2	Threshold 2	-40 ... -30 ... 90	-40 ... 194		
H4.LEVEL3	Threshold 3	-40 ... 90	-40 ... 194		
J. 	TMAX	Monitoring of the upper limit temperature with the following parameters:			
J1.TUNIT	Temperature unit	°C	°F	°C/°F	
J2.LEVEL1	Threshold 1	-40 ... 75 ... 90	-40 ... 194		
J3.LEVEL2	Threshold 2	-40 ... 80 ... 90	-40 ... 194		
J4.LEVEL3	Threshold 3	-40 ... 90 ... 90	-40 ... 194		
L. 	STRK	Monitoring of the path integral with the following parameters:			
L1.LIMIT	Limit value for the number of direction changes	1 ... 1E6 ... 1E8			
L2.FACT1	Factor 1	0.1 ... 1.0 ... 40.0			
L3.FACT2	Factor 2	0.1 ... 2.0 ... 40.0			
L4.FACT3	Factor 3	0.1 ... 5.0 ... 40.0			
O. 	DCHG	Monitoring of the direction changes with the following parameters:			
O1.LIMIT	Limit value for the number of direction changes	1 ... 1E6 ... 1E8			
O2.FACT1	Factor 1	0.1 ... 1.0 ... 40.0			
O3.FACT2	Factor 2	0.1 ... 2.0 ... 40.0			
O4.FACT3	Factor 3	0.1 ... 5.0 ... 40.0			
P. 	PAVG	Calculation of the average position value with the following parameters:			
P1.TBASE	Time base of the average value calculation	0.5h / 8h / 5d / 60d / 2.5y			
P2.STATE	State of the average position value calculation	IdLE / rEF / ###.# / Strt			
P3.LEVEL1	Threshold 1	0.1 ... 2.0 ... 100.0	%		
P4.LEVEL2	Threshold 2	0.1 ... 5.0 ... 100.0	%		
P5.LEVEL3	Threshold 3	0.1 ... 10.0 ... 100.0	%		

12 Service and maintenance

Basic safety instructions



WARNING

Impermissible repair of the device

Repairs may be carried out only by authorised personnel.



WARNING

Impermissible accessories and impermissible spare parts

Danger of explosion in potentially explosive areas or damage to the device.

- ▶ Use exclusively original accessories and original spare parts.
- ▶ Observe all relevant installation and safety instructions described in the manuals for the device, accessories and spare parts.



WARNING

Improper connection after maintenance

Danger of explosion in potentially explosive areas or damage to the device

- ▶ Connect the device correctly after maintenance.
- ▶ Close the device after maintenance.

CAUTION

Penetration of moisture into the interior of the device

Damage to the device

- Make sure that no moisture gets into the interior of the device during cleaning and maintenance work.



CAUTION

Cancelling the key lock

Improper changing of parameters can impair the process safety.

- ▶ Make sure that only authorised personnel cancel the key lock if the device is used for safety applications.



WARNING

Electrostatic charging

Danger of explosion in potentially explosive areas due to electrostatic charging, which can occur, for example, when cleaning housings with a dry cloth.

- ▶ Prevent electrostatic charging in potentially explosive areas.

**⚠ WARNING****Open housing**

Danger of explosion in potentially explosive areas due to hot components and/or charged capacitors in the interior of the housing.

► Switch the device off before opening it in a potentially explosive area.

⇒ **Exceptions:** devices of the ignition protection class Intrinsic Safety "Ex i" may also be opened in a potentially explosive area when switched on.

**⚠ WARNING****Dust deposits thicker than 5 mm**

Risk of explosion in potentially explosive areas. The device can heat up as a result of dust deposits.

► Remove dust deposits that are thicker than 5 mm.

The positioner requires almost no maintenance. Filters are fitted to the pneumatic connections to protect the positioner against large particles of dirt. Dirt present in the input air can collect on the filter and then adversely affect the operation of the positioner (increased travel time). In such a case, the filters can be cleaned as follows:

1. Switch off the auxiliary pneumatic energy and disconnect the hose lines.
2. Carefully remove the metal filters from the holes and clean them (e.g. with compressed air).
3. Insert the filters.
4. Connect the hose lines again and turn on the auxiliary pneumatic power.

13 Technical Data

General data for the basic device

Protection class	IP66 according to EN 60529
Climate class	according to IEC 721
Storage	1K5 but -40 °C to +80 °C ¹⁾
Transport	2K4, but -40 °C ... +80 °C ¹⁾
Operation	4K3, but -30 °C ³⁾ to +80 °C ²⁾ (Standard + FIP)
	4K3, but -40 ... +80 °C (LT) ²⁾
Vibration resistance	10 g to 100 Hz recommended continuous operating range for the complete valve: ≤ 30 m/s ²
CE mark	The applicable directives and standards, including their edition dates, are listed in the declaration of conformity.
Mounting position	Any orientation; in wet environments, ensure that pneumatic connections and the exhaust air vent do not face upward
Connections	
Electrical	Screw terminals 2.5 AWG28-12 Cable gland M 20x1.5 or Cable gland 1/2 –14 NPT
pneumatic	Internal thread G 1/4 DIN 45141 or Internal thread 1/4 –18 NPT

1) During startup, ensure that the positioner is purged with dry instrument air long enough when the temperature is ≤ 0 °C.

2) For explosion-proof devices, see the electrical data

3) The LCD display's refresh rate is limited at temperatures below -10 °C.

Pneumatic data for the basic device

Auxiliary power (air supply)	
Medium	Instrument air according to DIN ISO 8573-1, class 2
Pressure	1.4...7 bar (standard) / 3...7 bar (FIP)

Electrical data for the basic device

	Type 827A.E	Type 827A.X
Ex Marking	-	TÜV 12 ATEX 085253 X IECEX TUN 21.0016X
Ignition protection class	-	II 2 G Ex ia IIC T6...T4 Gb II 3 G Ex ic IIC T6...T4 Gc
Intrinsic safety		
Ambient temperature	-30 to +80 °C	T4 -30 ...+80 °C (standard + FIP) T6 -30 ...+60 °C (standard + FIP) T4 -40 ...+80 °C (LT) T6 -40 ...+60 °C (LT)

2-conductor circuit without HART	Type 827A.E	Type 827A.X
Current input I_W	4 ... 20 mA	
Current to maintain the auxiliary energy	≥ 3.6 mA	
Required load voltage U_B	≥ 6.5 V ($\approx 325 \Omega$)	≥ 8.3 V ($\approx 415 \Omega$)
Static destruction limit	± 40 mA	-
Internal capacitance C_i	-	11 nF
Internal inductance L_i	-	209 μ H
for connection to electrical circuits with the following maximum values	-	$U_i = 30$ V DC $I_i = 100$ mA $P_i = 1$ W
Digital Input BE1 (galvanically connected to the I_W circuit)	Usable for zero-potential contact Max. contact load $\leq 5 \mu$ A at 3 V	
2-conductor circuit with HART	Type 827A.E	Type 827A.X
Current input J_W	4 ... 20 mA	
Current to maintain the auxiliary energy	≥ 3.6 mA	
Required load voltage U_B	≥ 6.7 V ($\approx 340 \Omega$)	≥ 8.8 V ($\approx 440 \Omega$)
Static destruction limit	± 40 mA	-
Internal capacitance C_i	-	11 nF
Internal inductance L_i	-	209 μ H
for connection to electrical circuits with the following maximum values	-	$U_i = 30$ V DC $I_i = 100$ mA $P_i = 1$ W
Digital Input BE1 (galvanically connected to the I_W circuit)	For use with a zero-potential contact max. contact load $\leq 5 \mu$ A at 3 V	

Electrical Data for the Options

Ignition protection class	same as basic device ¹⁾
Ambient temperature	same as basic device ¹⁾

¹⁾ When using options with the same ignition protection class as the basic device, also refer to the basic device's electrical data.

Analog Output Module	Type 827A.E	Type 827A.X
Nominal signal range I_Y	4 to 20 mA, short-circuit-proof	
Output range	3.6 ... 20.5 mA	

Auxiliary voltage U_H	DC 12 ... 35 V	DC 12 ... 30 V
external load R_B	$R_B [k\Omega] \leq (U_H [V] - 12 V) / J_Y [mA]$	
Conversion error	$\leq 0.3 \%$	
Temperature influence	$\leq 0.1 \%$ / 10 K	
Resolution	$\leq 0.1 \%$	
Residual ripple	$\leq 1 \%$	
Internal capacitance C_i	-	2 nF
Internal inductance L_i	-	negligible
for connection to electrical circuits with the following maximum values	-	$U_i = 30 V$ DC $I_i = 100 mA$ $P_i = 1 W$
Galvanic isolation	to basic device	I_Y (tml. 61/62) and the basic device are individual, intrinsically safe electrical circuits
Test voltage	DC 840 V, 1 s	
Binary module (DIO) identified by 5=B	Type 827A.E	Type 827A.X
Digital outputs A1, A2, I		
Signal state high (not activated)	conductive $R = 1 k\Omega$ ^{+3% / -1%}	$\geq 2.1 mA$ ²⁾
Signal state low (activated) ³⁾	blocked $I_R < 60 mA$	$\leq 1.2 mA$ ²⁾
Internal capacitance C_i	-	5.2 nF
Internal inductance L_i	-	negligible
Auxiliary voltage U_H	$\leq DC 35 V$	-
for connection to electrical circuits with the following maximum values	-	$U_i = 15 V$ DC $I_i = 25 mA$ $P_i = 64 mW$
Digital input BE2		
Terminal 21/22 (galvanically connected to basic device)	For use with a zero-potential contact max. contact load $\leq 5 \mu A$ at 3 V	
Terminal 11/12 (galvanically isolated)		
Signal state 0	$\leq DC 4.5 V$ or open	
Signal state 1	$\geq DC 13 V$	
Input resistance	$\geq 25 k\Omega$	
Static destruction limit	$\pm 35 V$	-
Internal capacitance C_i	-	negligible
Internal inductance L_i	-	negligible

for connection to electrical circuits with the following maximum values	-	$U_i = 25.2 \text{ V DC}$
Galvanic isolation	A1, A2, I_i , BE2 (tml. 11/12) to each other and to the basic device	A1, A2, I_i , BE2 (tml. 11/12) and the basic device are individual, intrinsically safe electrical circuits
Test voltage	DC 840 V, 1 s	

2) Switching thresholds for supply according to DIN EN 60947-5-6 (formerly DIN 19234): $U_H = 8.2 \text{ V}$; $R_i = 1 \text{ k}\Omega$.

3) "low" is also the state when the basic device is faulty or has no auxiliary electrical energy.

Digital I/O Module (DIO-2) identified by 5=D	Type 827A.E	Type 827A.X
Digital outputs A1, A2, I_i		
Signal state high (not activated)	conductive $R = 1 \text{ k}\Omega^{+3\% / -1\%}$	$\geq 2.1 \text{ mA}^{2)}$
Signal state low (activated) ³⁾	blocked $I_R < 60 \text{ mA}$	$\leq 1.2 \text{ mA}^{2)}$
Internal capacitance C_i	-	5.2 nF
Internal inductance L_i	-	negligible
Auxiliary voltage U_H	$\leq \text{DC } 35 \text{ V}$	-
for connection to electrical circuits with the following maximum values	-	$U_i = 17.5 \text{ V DC}$ $I_i = 100 \text{ mA}$ $P_i = 250 \text{ mW}$
Digital input BE2		
Terminal 21/22 (galvanically connected to basic device)	For use with a zero-potential contact max. contact load $\leq 5 \mu\text{A}$ at 3 V	
Terminal 11/12 (galvanically isolated)		
Signal state 0	$\leq \text{DC } 4.5 \text{ V}$ or open	
Signal state 1	$\geq \text{DC } 13 \text{ V}$	
Input resistance	$\geq 25 \text{ k}\Omega$	
Static destruction limit	$\pm 35 \text{ V}$	-
Internal capacitance C_i	-	negligible
Internal inductance L_i	-	negligible
for connection to electrical circuits with the following maximum values	-	$U_i = 32 \text{ V DC}$
Galvanic isolation	A1, A2, I_i , BE2 (tml. 11/12) to each other and to the basic device	A1, A2, I_i , BE2 (tml. 11/12) and the basic device are individual, intrinsically safe electrical circuits
Test voltage	DC 840 V, 1 s	

2) Switching thresholds for supply according to DIN EN 60947-5-6 (formerly DIN 19234): $U_H = 8.2 \text{ V}$; $R_i = 1 \text{ k}\Omega$.

3) "low" is also the state when the basic device is faulty or has no auxiliary electrical energy.

Slot-type initiator module (ILS) identified by 5=S	Type 827A.E	Type 827A.X
Digital outputs A1, A2		
Slot-type initiators	Type SJ2-SN or N7S20A, 2-wire connection, normally closed function (NC)	
Connection	to switching amplifier DIN EN 60947-5-6 (formerly DIN 19234)	
Internal capacitance C_i	-	36 nF
Internal inductance L_i	-	100 μH
for connection to electrical circuits with the following maximum values	$U_{\text{Nom}} = 8 \text{ V}$	$U_i = 15 \text{ V DC}$ $I_i = 25 \text{ mA}$ $P_i = 64 \text{ mW}$
Digital output I_i		
Signal state high (not activated)	$R = 1.1 \text{ k}\Omega$	$\geq 2.1 \text{ mA}^{1)}$
Signal state low (activated) ²⁾	$R = 10 \text{ k}\Omega$	$\leq 1.2 \text{ mA}^{1)}$
Internal capacitance C_i	-	5.2 nF
Internal inductance L_i	-	negligible
Auxiliary voltage U_H	$\leq \text{DC } 35 \text{ V}$	-
for connection to electrical circuits with the following maximum values	-	$U_i = 15 \text{ V DC}$ $I_i = 25 \text{ mA}$ $P_i = 64 \text{ mW}$
Galvanic isolation	A1, A2, I_i to each other and to the basic device	A1, A2, I_i and the basic device are individual intrinsically safe electrical circuits
Test voltage	DC 840 V, 1 s	

1) Switching thresholds for supply according to DIN EN 60947-5-6 (formerly DIN 19234): $U_H = 8.2 \text{ V}$; $R_i = 1 \text{ k}\Omega$.

2) "low" is also the state when the basic device is faulty or has no auxiliary electrical energy.

Inductive Limit Switch module (ILS-2) identified by 5=I	Type 827A.E	Type 827A.X
Digital outputs A1, A2		
Slot-type initiators	Type SJ2-SN or N7S20A, 2-wire connection, normally closed function (NC)	
Connection	to switching amplifier DIN EN 60947-5-6 (formerly DIN 19234)	
Internal capacitance C_i	-	36 nF
Internal inductance L_i	-	100 μH

for connection to electrical circuits with the following maximum values	$U_{\text{Nom}} = 8 \text{ V}$	$U_i = 16 \text{ V DC}$ $I_i = 25 \text{ mA}$ $P_i = 64 \text{ mW}$
Digital output¹		
Signal state high (not activated)	$R = 1.1 \text{ k}\Omega$	$\geq 2.1 \text{ mA}^{1)}$
Signal state low (activated) ²⁾	$R = 10 \text{ k}\Omega$	$\leq 1.2 \text{ mA}^{1)}$
Internal capacitance C_i	-	5.2 nF
Internal inductance L_i	-	negligible
Auxiliary voltage U_H	$\leq \text{DC } 35 \text{ V}$	-
for connection to electrical circuits with the following maximum values	-	$U_i = 17.5 \text{ V DC}$ $I_i = 100 \text{ mA}$ $P_i = 250 \text{ mW}$
Galvanic isolation	A1, A2, ¹ to each other and to the basic device	A1, A2, ¹ and the basic device are individual intrinsically safe electrical circuits
Test voltage	DC 840 V, 1 s	

1) Switching thresholds for supply according to DIN EN 60947-5-6 (formerly DIN 19234): $U_H = 8.2 \text{ V}$; $R_i = 1 \text{ k}\Omega$.

2) "low" is also the state when the basic device is faulty or has no auxiliary electrical energy.

Contact module (MLS) identified by 5=K	Type 827A.E	Type 827A.X
Digital outputs A1, A2		
Limit monitor	mechanical switching contacts	
max. switching voltage	30 V DC	30 V DC
max. switching current	4 A	-
Internal capacitance C_i	-	negligible
Internal inductance L_i	-	negligible
for connection to electrical circuits with the following maximum values	-	$U_i = 30 \text{ V DC}$ $I_i = 100 \text{ mA}$ $P_i = 750 \text{ mW}$
Digital output¹		
Signal state high (not activated)	$R = 1.1 \text{ k}\Omega$	$\geq 2.1 \text{ mA}^{1)}$
Signal state low (activated) ²⁾	$R = 10 \text{ k}\Omega$	$\leq 1.2 \text{ mA}^{1)}$
Internal capacitance C_i	-	5.2 nF
Internal inductance L_i	-	negligible
Auxiliary voltage U_H	$\leq \text{DC } 35 \text{ V}$	-

for connection to electrical circuits with the following maximum values	-	$U_i = 15 \text{ V DC}$ $I_i = 25 \text{ mA}$ $P_i = 64 \text{ mW}$
Galvanic isolation	A1, A2, I_i to each other and to the basic device	A1, A2, I_i and the basic device are individual, intrinsically safe electrical circuits
Test voltage	840 V, 1 s	

1) Switching thresholds for supply according to DIN EN 60947-5-6 (formerly DIN 19234): $U_H = 8.2 \text{ V}$; $R_i = 1 \text{ k}\Omega$.

2) "low" is also the state when the basic device is faulty or has no auxiliary electrical energy.

Mechanic Limit Switch module (MLS-2) identified by 5=M	Type 827A.E	Type 827A.X
Digital outputs A1, A2		
Limit monitor	mechanical switching contacts	
max. switching voltage	30 V DC	30 V DC
max. switching current	4 A	-
Internal capacitance C_i	-	negligible
Internal inductance L_i	-	negligible
for connection to electrical circuits with the following maximum values	-	$U_i = 30 \text{ V DC}$ $I_i = 100 \text{ mA}$ $P_i = 750 \text{ mW}$
Digital output I_i		
Signal state high (not activated)	$R = 1.1 \text{ k}\Omega$	$\geq 2.1 \text{ mA}^{1)}$
Signal state low (activated) ²⁾	$R = 10 \text{ k}\Omega$	$\leq 1.2 \text{ mA}^{1)}$
Internal capacitance C_i	-	5.2 nF
Internal inductance L_i	-	negligible
Auxiliary voltage U_H	$\leq \text{DC } 35 \text{ V}$	-
for connection to electrical circuits with the following maximum values	-	$U_i = 17.5 \text{ V DC}$ $I_i = 100 \text{ mA}$ $P_i = 250 \text{ mW}$
Galvanic isolation	A1, A2, I_i to each other and to the basic device	A1, A2, I_i and the basic device are individual, intrinsically safe electrical circuits
Test voltage	840 V, 1 s	

1) Switching thresholds for supply according to DIN EN 60947-5-6 (formerly DIN 19234): $U_H = 8.2 \text{ V}$; $R_i = 1 \text{ k}\Omega$.

2) "low" is also the state when the basic device is faulty or has no auxiliary electrical energy.

Analog Input Module (AIM)	Type 827A.E	Type 827A.X
Resistance of the external potentiometer	10 k Ω	
for connection to electrical circuits with the following maximum values	-	$U_0 = 5 \text{ V DC}$ $I_0 = 100 \text{ mA}$ $P_0 = 33 \text{ mW}$
external capacitance C_0	-	1 μF
external inductance L_0	-	1 mH
Galvanic isolation	connected to basic device	

14 Fault removal

Diagnostic guide

	See Table			
In which operating mode does the fault appear?				
▪ Initialization	1			
▪ Manual operation and automatic operation	2	3	4	5
In what environment and under what conditions does the error occur?				
▪ Wet environments (such as heavy rain or continuous condensation)	2			
▪ Vibrating (oscillating) valves	2	5		
▪ Impact or shock loading (e.g. "steam hammering" or breakaway flaps)	5			
▪ Humid (wet) compressed air	2			
▪ Dirty compressed air (contaminated with solid particles)	2	3		
When does the fault appear?				
▪ Continuously (reproducible)	1	2	3	4
▪ Sporadically (not reproducible)	5			
▪ Usually after a certain period of operation	2	3	5	

Table 1

Fault symptoms	possible cause(s)	Remedial measures
Positioner remains in "RUN 1" mode.	▪ Initialization started from end position and ▪ Did not wait for the maximum 1-minute reaction time. ▪ Mains pressure not connected or too low.	▪ up to 1 min waiting time required ▪ Do not start initialization from end position ▪ Ensure proper system pressure
Positioner remains in "RUN 2" mode.	▪ Stroke on lever incorrectly adjusted. ▪ Piezo valve(s) are not switching (see Table 2).	▪ Check stroke adjustment on lever ▪ see Table 2
Positioner remains in "RUN 3" mode.	▪ Actuator travel time too long	▪ Open restrictor completely and/or set P_z pressure to highest permissible value. ▪ consider using a booster
Positioner remains in "RUN 5" mode, does not get to "FINISH" (waiting time > 5 min).	▪ "Slack" (play) in the positioner - actuator - valve system	▪ Rotary actuator: Check that the grub screw on the coupling wheel is tight ▪ Linear actuator: Check that the lever on the positioner shaft is tight ▪ Eliminate any other play between the actuator and the valve.

Table 2

Fault symptoms	possible cause(s)	Remedial measures
▪ “CPU test” flashes in the display (approx. every 2 s) ▪ Piezo valve(s) is/are not switching.	▪ Water in the valve block (caused by wet compressed air)	▪ In the early stages, the problem can be corrected by further operation in dry air (if necessary, in a temperature chamber at 50 to 70 °C). ▪ otherwise repair
▪ Actuator will not move at all or only in one direction in both manual and automatic operating modes.	▪ Moisture in the valve block	
▪ The piezo valve(s) is/are not switching (not even a faint “click” is audible when pressing the  or  button in manual mode)	▪ The screw between the basic electronics and the valve block is not tightened properly	▪ Tighten the screws
	▪ Debris (chips, particles) in the valve block	▪ Repair or new device
	▪ Deposits on the contact(s) between the electronics board and valve block can result from wear caused by continuous exposure to severe vibration.	▪ Clean all contact surfaces with denatured alcohol. If necessary, slightly bend the valve-block contact springs back into shape

Table 3

Fault symptoms	possible cause(s)	Remedial measures
▪ Actuator does not move	▪ Compressed air < 1.4 bar	▪ Set incoming air pressure to > 1.4 bar.
▪ The piezo valve(s) is/are not switching (but a faint “click” is audible when pressing the  or  button in manual mode).	▪ Restrictor valve(s) closed (screw(s) at the clockwise stop)	▪ Open restrictors by turning counterclockwise
	▪ Dirt in the valve block	▪ Repair or new device
▪ In steady-state automatic mode (constant setpoint) and in Manual mode, a piezo valve switches continuously.	▪ Pneumatic leak in the positioner - actuator system. Begin leak test in “RUN 3” (initialization)	▪ Eliminate the leak in the actuator and/or supply line ▪ If the actuator is intact and the supply line is leak-tight: Repair or new device
	▪ Dirt in the valve block (see above)	▪ Repair or new device

Table 4

Fault symptoms	possible cause(s)	Remedial measures
▪ In steady-state automatic mode (constant setpoint) and in manual mode, both piezo valves switch back and forth continuously, and the actuator oscillates around a mean value.	▪ Static friction in the stuffing box of valve or actuator too high	▪ Reduce static friction or increase dead zone (parameter DEBA) until the oscillating movement stops.
	▪ “Slack” (play) in the system ▪ positioner - actuator - valve	▪ Rotary actuator: Check that the grub screw on the coupling wheel is tight

		▪ Linear actuator: Check that the lever on the positioner shaft is tight. ▪ Eliminate any other play between the actuator and the valve.
	▪ Actuator too fast	▪ Increase the actuating times using the restrictor screws. ▪ If fast actuating time is required, increase dead zone (parameter DEBA) until the oscillation stops.
▪ Positioner does not drive valve up to the stop (with 100 % input signal)	▪ Supply pressure too low	▪ Increase supply pressure
	▪ The load voltage of the supply controller or system output is too low.	▪ Interpose load transformer

Table 5

Fault symptoms	possible cause(s)	Remedial measures
▪ No device function at all, also no display	▪ Electrical auxiliary energy source inadequate (< 3.6 mA)	▪ check electrical auxiliary energy source.
	▪ In cases of very high continuous stress caused by vibrations:	
	▪ screws on the electrical connecting terminals may come loose ▪ electrical connecting terminals and/or electronic components may be loosened by vibration	▪ Tighten screws and secure with sealant ▪ Repair ▪ for prevention: install positioner on rubber-metal mounts



15 Disposal and recycling

WARNING

Operating media and auxiliary materials that are hazardous to health

Danger to people and the environment!

- ▶ Wear suitable protective equipment
- ▶ If applicable, collect and dispose of rinsing medium or residual medium. Particular attention is to be paid to dead spaces (pressure compensation, bellows, etc.)
- ▶ Observe the legal regulations for the disposal of media that are hazardous to health

ARCA products are modularly constructed and can be sorted by material into the following components.

- Electronic components
- Metals
- Plastics
- Greases and oils
- Packaging material

The general rules are:

- greases and oils are usually water pollutants and must not be allowed to escape into the environment
- Dispose of dismantled materials properly or recycle the separate materials
- Observe national disposal regulations



www.arca-valve.com